

RVA1288BWC

MIXING BOWL PLATFORM

RUVATI[®]
SPECIFICATION SHEET

Material: Food-safe Solid Composite

Size: 17-1/4" (length) x 15-3/4" (width) x 3/8" (thick)

Compatible Ruvati Sinks:

RVG1302, RVG1306, RVG2302, RVG2306, RVH5003, RVH6222, RVH6333, RVH6527, RVH6530, RVH6533, RVH8002, RVH8003, RVH8023, RVH8030, RVH8035, RVH8036, RVH8222, RVH8224, RVH8300, RVH8301, RVH8307, RVH8308, RVH8309, RVH8310, RVH8320, RVH8324, RVH8253, RVH8255, RVH8277, RVH8299, RVH8300, RVH8301, RVH8303, RVH8304, RVH8307, RVH8308, RVH8309, RVH8310, RVH8320, RVH8324, RVH8327, RVH8333, RVH8335, RVH8341, RVH8345, RVH8350, RVH8351, RVH8356, RVH8359, RVH8424, RVH8433, RVH8555, RVH8570, RVH8573, RVH8582, RVH8584, RVH8591, RVH8596, RVH8597, RVH8630, RVH8633, RVH8666, RVH9020, RVH9050, RVH9100, RVH9106, RVH9200, RVH9201, RVH9207, RVH9222, RVH9300, RVH9301, RVH9308, RVH9333, RVL2387, RVU6320, RVU6321, RVU6327, RVU6421, RVU6425

CARE INSTRUCTIONS



Cleaning: Hand wash the plastic cutting board with soap and hot water or run it through the dishwasher.



Disinfecting: You can disinfect the board by soaking it for 2 minutes in a solution of two teaspoons of bleach and one gallon of water.



Deodorize: Wet the board and sprinkle it with baking soda. Let it stand for a few minutes then rinse it in water.



Scratches: It is normal for plastic cutting boards to take knife marks. The scratches will be noticeable when the board is new. Over time, they will blend in.



Heat: Do not expose the cutting board to hot surfaces, or put in an oven or microwave. It can cause the board to melt.



RUVATI USA

www.ruvati.com